



Ringle. Components

LEVEL 3 COLLECTOR POSITIONING

CAMCRAFT shower set

STD - 100mm - 100 grams per pair

Place a dab of glue on the threads and a drop of oil on the pivot pin. Adjust the unit so that it will close as snug as possible with a smooth cover sheet. After closing, bend the lever approximately 180 to 170 turns in a clockwise direction to fully tighten the wheel. Levers should point back and up (large black holes may require that the cover be installed on the drive side).

If the cover that shower requires shortening - mark the unit, disassemble, then cut. Grind or file the end smooth before reassembling.

Single Components